1. Open the IE browser, enter the device IP. Camera default IP: 192.168.1.10(NVR default IP: 192.168.1.9)

As shown like below:



2. Open the options one by one: tools>>Internet options >>security>> custom level and then enable the options with ActiveX . As shown like below:

Jecungs		
	Disable	-
	Enable	ural
	Disable	urey
(	Enable (not secure)	
	Prompt (recommended)	
🥥 C	ownload unsigned ActiveX controls (not s	ecure)
- (	Disable (recommended)	
	Enable (not secure)	
	) Prompt	
J I	nitialize and script ActiveX controls not ma	arked as sate for s
9	Disable (recommended)	
0	Enable (not secure)	
	) Prompt only allow approved domains to use Active	X without promot
	Disable	*
•	m	•
*Takes eff	fect after you restart Internet Explorer	
Reset custo	msettings	_
Decet to:	Madium biob (default)	Pecet

3. After successfully saved, refresh the web page, choose to install the Active control according to clew, as shown like below:

)o vou v	vant to run or save this file?
	Name: NewActive.exe Type: Application, 3.04MB From: <b>xmsecu.com</b> Run Save Cancel
I P	Vhile files from the Internet can be useful, this file type can otentially harm your computer. If you do not trust the source, do not un or save this software. What's the risk?

4. After the success of the installation, there will be a login box interface, enter the user name: admin, password: empty. Enter the preview interface. As shown like below:

